

### 2019+ Hyundai Veloster

sku 3-847HY020

These installations show the right door (passenger side) deflectors being installed as the Veloster does not have rear door on the driver side. The same procedure applies to installing the driver side) deflectors. Be careful not to damage the paint finish and glass run channels/weather-strips when installing the deflectors.

Adhesive strength is determined by the adhesive viscosity and resin softness. The lower the atmospheric temperature, the lower the adhesive viscosity and weaker the adhesive strength. For this reason, installation is best when the ambient air temperature is 65F or above.

**Important:** If dirt, dust, or oil are present on the surface of the window frame for installation, the adhesive strength of the 3M tape will be diminished. For best result, thoroughly clean the surface of the window/door frame where deflector will be attached using cleaning pad and rag. Do not touch the 3M tape surface with hands. This will cause oil from the skin to be transferred to the 3M tape, diminishing the adhesive strength of the tape.



#### Step 1

Open the door and fully open the front and rear windows to allow more space to work around the window frames. Important: Thoroughly clean the surface of the window/door frame where deflector will be attached using cleaning pad and rag. Wait for surface to dry before proceeding to the next step.

#### Step 2

Hold the deflector up the window frame to ensure proper fitment and to get an idea on where to mount the brackets. Remove the protective black foam from the hooks.

#### Step 3

There are 4 self-adhesive black foam inside the box. Remove the backings from the black foam. Adhere the black foams to both sides of the side mirror locations, also near the handle on the passenger side rear door. See below illustrations. This is to avoid leakage.



#### Step 4

Peel off the side adhesive backing from the visor, and peel back 1 1/2 to 2 inches of each end of the top adhesive backing.

### Step 5

Line up the visor with the door frame and mount the visor to the top edge of the door frame with the pre-installed mounting bracket. See image.

### Step 6

Make sure the adhesive backing is hanging under the visor, not above, as you'll be pulling the backing from under the visor. See images

### Step 7

Lightly tape front end and rear end of visor on to door frame. Carefully remove the adhesive backings and apply pressure to the adhesive area. While peeling off the backings, grab the backing as close to the visor as possible and pull slowly to avoid tearing the tape.

### Step 8

Press down evenly on the visor where the double-sided adhesive tapes are attached.

### Step 9

Raise and lower the window several times to see if window can be closed properly.

### Step 10

Check visor from above and below to make sure adhesive tape is fully contacted with door frame (no gap between adhesive and door frame. **TIPS: check for light leak**). If visor is not fully contacted with door frame, apply pressure on the edge of the visor again to ensure adhesive is fully contact with door frame.

### Step 11

Repeat the same procedure to install the rear visor.



Visit our youtube channel for visual installation guide <https://www.youtube.com/user/wellvisors>  
Contact us [wellvisors@gmail.com](mailto:wellvisors@gmail.com) | Tel. 1-844-WVISORS (984-7677)